



REMOTE GUIDE



PROGRAM REMOTE TO TV

Under **Settings** -> **Device Preferences** -> **Smart Control** you can program the remote to the TV.



MANUAL REMOTE CONTROL UPDATE PROCESS

- 1 Under **Settings** -> **Device Preferences** -> **Smart Control** you can update your remote control.
- 2 If your **TV brand** is automatically found, it will show in the window as shown to the right, simply check **Yes** to continue.
- 3 If your TV brand is **not automatically found**, you can type in the brand of the TV as shown.
- 4 Once you have validated the **TV Power button works**, choose **Yes** to continue.
- 5 Once you have validated the **Source button works**, choose **Yes** to continue.

